Netgear WNDR3800

Modified on: Fri, 20 Feb, 2015 at 10:11 AM

Please connect an Ethernet cable from your existing modem/router/network in to the port labelled "**Internet**" on the back of the Netgear.



Please connect an Ethernet cable between port 1 on the back of the Netgear and your computer.

Turn on the router and wait for a few minutes.

Open a web browser and type http://192.168.1.1 in to the address bar.

Authentication Required					
The server http://192.168.1.1:80 requires a username and password. The server says: NETGEAR WNDR3800.					
User Name:	admin				
Password:	*****				
	Log In Cancel				

You will be prompted to log-in. The default username is "**admin**" and the password is "**password**" unless you have changed these.

Click on "Advanced" on the top menu.

	Router Firmware	jout Version /1.0.0.44
BASIC ADVANCED	Auto	-
ADVANCED Home	Firmware Upgrade	
Setup Wizard WPS Wizard	Check for New Version from the Internet.	
► Setup	Locate and Select the Upgrade File from your Hard Disk: Choose File ng-wndr3800.img	
► USB Storage	× Cancel Upload	
► Security	v Gancer Opload	
→ Administration		
Router Status Logs Attached Devices Backup Settings Set Password Firmware Upgrade		

Click "Administration" on the left menu.

Click "Firmware Upgrade" on the left.

Click "Choose File" and browse to the firmware file that you have been provided.

NOTE: If you receive an error, please rename the file extension to .img instead of .bin. So the full file name will be ng-wndr3800.img and try uploading again.

Click "Yes" to confirm the firmware upgrade.

NETGEAR [®] G	leuie	Router Firmware Version V1.0.0.44
BASIC ADVANCED		Auto
ADVANCED Home	Updating Settings	
Setup Wizard		
WPS Wizard		
► Setup		
► USB Storage		
► Security		
▼ Administration		
Router Status		
Logs		
Attached Devices		
Backup Settings		
Set Password		
Firmware Upgrade		

The upgrade process will now begin. This takes up to 5 minutes to complete.