

On Networks N150R

Modified on: Fri, 20 Feb, 2015 at 10:12 AM


Please connect an Ethernet cable from your existing modem/router/network in to the WAN port on the back of the router.

Connect an Ethernet cable between port 1 on the back of the router and your computer

Turn on the router and wait for a few minutes

Open a web browser and type **http://192.168.1.1** in to the address bar

The default username is "admin" and the password is "admin" (unless you have changed these prior).



Authentication Required

The server http://192.168.1.1:80 requires a username and password. The server says: On Networks N150R.

User Name:

Password:

Click on Management and then Update Firmware, click on "**Browse**" and select the firmware file that you have been provided.

HOME	SETUP	SECURITY
Router Status	Firmware Update	
Log	Check for new version from the Internet.	
Client Devices	Locate and select the upgrade file on your hard disk.	
Backup Settings	<input type="button" value="Choose File"/> on-n150r.img	
Change Password	<input type="button" value="Upload"/> <input type="button" value="Cancel"/>	
Update Firmware		

Click on **Upload** and Click **Yes**. The upgrade process will now begin and take up to 5 minutes to complete.