

TP-Link


Modified on: Fri, 20 Feb, 2015 at 9:39 AM

Please connect an Ethernet cable from your existing modem/router/network in to the port labelled "Internet/WAN" on the back of the TP-Link

Connect an Ethernet cable between port 1 on the back of the TP-Link and your computer


Turn on the router and wait for a few minutes

Open a web browser and type **http://192.168.0.1** in to the address bar




You will be prompted to log-in. The default username is "**admin**" and the password is "**admin**" (unless you have changed these prior).

Click on "**System Tools**" on the left menu



Click on "**Firmware Upgrade**" on the left menu

Click on "**Browse**" and select the firmware file that you have been provided



Click on "**Upgrade**" and press "**OK**" to confirm. The upgrade process will now begin and take up to 5 minutes to complete.

